

AMPS Installation Notes

Version A-2007.12

December 10, 2007

These installation notes present information about installing AMPS version A-2007.12 in the following sections:

- [Media Availability and Supported Platforms](#)
- [Disk Space and Memory Requirements](#)
- [Installing the Software](#)
- [Setting Up the User Environment](#)
- [Verifying the AMPS Installation](#)

AMPS is packaged with PathMill in the electronic software transfer (EST) download directory (*pathmill_vversion*) and is available on the PathMill CD/DVD. To ensure a successful installation, complete the following procedures before beginning the installation process:

- Create the Synopsys root directory.
- Define the `SYNOPSYS` environment variable.

See also <http://www.synopsys.com/install> for additional installation and licensing information.

Copyright © 2007 Synopsys, Inc. All rights reserved. See <http://www.synopsys.com/copyright.html> for additional terms and conditions.

Media Availability and Supported Platforms

AMPS is available by EST download. At a later date, it becomes available on DVD (or CD depending on image size). Obtain the appropriate binary executable files based on the operating system you need. [Table 1-1](#) shows the supported platforms for the version A-2007.12 release.

Table 1-1 Supported Platforms and Keywords

Platform	Operating system	Synopsys platform keyword
AMD Opteron	Red Hat Enterprise Linux v4, v5 ¹	amd64 (64-bit mode) linux (32-bit mode) ²
EMT64T	SUSE Enterprise Linux 9, 10	suse64 (64-bit mode) suse32 (32-bit mode)
IA-32 (X86)	Red Hat Enterprise Linux v4, v5 ¹	linux (32-bit mode) ²
Sun SPARC	Solaris 9, 10	sparcOS5 (32-bit mode)

1. *Binary-compatible hardware platform or operating system. Note, however, that binary compatibility is not guaranteed.*

2. *The 32-bit (x86) Linux software is binary compatible with Intel EM64T or AMD Opteron running Red Hat Enterprise Linux. Note, however, that binary compatibility is not guaranteed.*

Disk Space and Memory Requirements

The AMPS tool has the following minimum memory requirements:

- Physical Memory – 256 MB (1 GB recommended)
- Swap space – 512 MB (2 GB recommended)

The disk space requirement varies, depending on the platform and tool selected for installation. During the installation process, Synopsys Installer displays the required disk space.

Installing the Software

The AMPS uses the Synopsys Installer tool, which allows you to use a text script or a graphical user interface (GUI). For information about downloading the Synopsys Installer and AMPS, see the document *Installing Synopsys Tools* at <http://www.synopsys.com/install>.

To install the AMPS follow the procedures described in *Installing Synopsys Tools*. This document provides a Synopsys media installation script. AMPS is installed in a similar manner. The AMPS cannot be installed over an existing Synopsys product, including a prior version of the AMPS.

Setting Up the User Environment

To set up the user environment, you must specify the location of the executable file and set the license environment variable.

Specifying the Executable File Location

Add the AMPS directory containing the executable file to the PATH environment variable.

If you are using the C shell, add the following line to the `.cshrc` file:

```
set path=($SYNOPTSYS/platform/amps/bin $path)
```

If you are using the Bourne, Korn, or Bash shell, add the following line to the `.profile` or `.kshrc` file:

```
PATH=$SYNOPTSYS/platform/amps/bin:$PATH
export PATH
```

Replace *platform* with the appropriate platform (see “[Media Availability and Supported Platforms](#)”).

Setting the SNPSLMD_LICENSE_FILE Environment Variab

You must install the Synopsys Common Licensing (SCL) software and define the `SNPSLMD_LICENSE_FILE` variable before you can verify the AMPS installation. For information about downloading SCL, installing SCL, or setting the license variable, see *Installing Synopsys Tools* at <http://www.synopsys.com/install>.

Verifying the AMPS Installation

To verify the AMPS installation,

1. Make sure you are in a directory where you have read/write privileges:

```
% cd $HOME
```

2. Invoke the tool by entering the following command:

```
% $SYNOPSYS/platform/amps/bin/amps
```

Replace *platform* with the appropriate platform (see [“Media Availability and Supported Platforms”](#)).

If you see information about the product version, production date, and copyright, the installation was successful.